

Designing to avoid shaded areas of a site

Shade from trees and landforms can be avoided by building higher on a site or by using skylights or clerestory windows. Taller buildings will increase the amount of shaded area on a site.

© BRANZ 2007

