



XPS sliver used as a thermal break at slab edge. The sliver will need to be forced over the reinforcing between slab and foundation wall. Fill any gaps after installation with expanding foam.