



Suspended timber floor with bulk insulation and lining
For open subfloors, a sheet lining material such as plywood, tempered hardboard or fibre-cement must be used to protect the insulation.

© BRANZ 2011