



Diversion of laundry and bathroom greywater for pumped irrigation

This can only be done if there is sufficient distance between the floor level and the outside ground level to allow a gravity feed to the surge tank. It entails a valve on the appropriate waste pipes to divert the wastewater to the surge tank. The pipes may be individual or combined wastes from the laundry and bathroom (but not from the kitchen). Water is then pumped to the irrigated area.

© BRANZ 2007