


**Branch drain venting**

© BRANZ 2009

branch drain vents must be sized correctly

the drain vent must be downstream from the head of the drain but not more than 10 m from it

every drain branch that exceeds 10 m must be vented



the main drain vent must be 80 mm min.

head of drain

access point (AP)

the main drain vent must be an open vent

main sewer

site boundary